



1. Thread each IBC x BSP adaptor to each MDPE elbow adaptor.



2. Insert PL pipe liners into both ends of each section of MDPE pipe.



3. Insert the pipes between the elbows and tee pieces. Twist the collars to tighten.



4. Thread the 1" female coupling onto the 1" BSP bib tap.



5. Thread the coupling onto the MDPE tee piece until firmly secured.



6. Align the connector kit with your IBCs valves and thread the IBC connectors on.



Congratulations, you now have a secure and robust tap to draw from multiple IBCs

Kit Contents



Tel: 01777 858009
Sales@kingfisherdirect.co.uk