



THE CITY WATER GARDEN

INSTALLATION GUIDE

Ecosure
Etills Ltd
Unit 1
Whiting Way
Melbourn
Hertfordshire
SG8 6NA

Phone: 01763 261781
Fax: 01763 268409
Email: sales@ecosure.co.uk
Website: www.ecosure.co.uk





CITY WATER GARDEN INSTALLATION GUIDE

RAINWATER DIVERTERS MUST BE INSTALLED BELOW THE BOTTOM OF THE BOWL OF THE PLANTER.

a. Position the water butt a maximum of 500mm from the rainwater downpipe.



b. Using a 26mm hole-saw or spade bit, cut a hole just below the base of the planter bowl and insert the rubber seal.



c. Fit the rainwater diverter to the downpipe according to the manufacturer's installation instructions.



d. Trim the connecting pipe if required, and push one end on to the diverter. Push the other end through the seal fitted onto the tank. Lubricate if necessary.



e. If, when fixing a tap to the raised outlet, the tap does not face downwards, use another layer of PTFE and try again. Do not use too much tape as this may damage the threaded outlet. Hand tighten only; do not use a spanner or wrench.



THANK YOU

Thank you for buying the City Water Garden. We hope you will be satisfied with your purchase. This industrial strength product is guaranteed frost-proof and is made from UV stabilised polymer.

IMPORTANT SAFETY INSTRUCTIONS

The Ecosure City Water Garden must be sited on a flat, level base. For installation guidance, please watch the promotional video at ecosure.co.uk

- Choose which outlet(s) you wish to use and drill out the plastic seal behind, being careful not to damage the threaded outlet.
- When fixing your tap or valve to the moulded outlets, use 4 or 5 layers of PTFE tape and DO NOT OVERTIGHTEN. Hand tighten only; do not use a spanner or wrench.
- When using any power tools, be aware of others around you and wear suitable PPE (e.g. eye protectors and gloves).