

User guidelines

Mini & Midi Envirobin



Cleaning Products should be flushed with clean water and then washed with a mild detergent solution using a bristle brush or sponge. Care should be taken not to apply undue pressure that may damage labels. Flush clean with water after washing.



Tools



Manufacturing Standard Products are manufactured to BS EN ISO 9001: 2008



PPE Always wear appropriate PPE equipment and follow safety guidelines.

Removing the lid *(for non-lockable options ignore steps 1 & 9)*



1 Turn key anti clockwise to unlock lid.



2 Lift lid from the front end, tilting backwards to free from rear locator.



3 With two hands lift the lid clear of the body & put to one side.

Inserting Sack



4
Locate sack around the rear of the body.
Slide the edges of the sack into the gap in the moulding.



5
Pull the sack taut and locate around the upper rim of the bin body at the front of the body



6
Sack is taut and secured in bin body

Replacing lid



7
Locate the rear peg of the lid under the lip at the back of the body.



8
Allow the lid to drop into position ensuring the front peg locates in the body.



9
Push the lock firmly fixing the lid in place.