


User Guidelines

Internal Recycling

Meridian Envirobin



Cleaning Products should be flushed with clean water and then washed with a mild detergent solution using a bristle brush or sponge. Care should be taken not to apply undue pressure that may damage labels. Flush clean with water after washing.



Manufacturing Standard (as applicable)
 manufactured to BS EN ISO 9002.
 Plastic materials: Mechanical properties tested to BS 2782 Hot dipped galvanised: BS 729.
 Powder coating: BS 3900 Zinc coating: BS1706



PPE Always wear appropriate PPE equipment and follow safety guidelines.

Removing Lid



Lift lid from front end, tilting backwards to free from rear locator



Lift the lid clear of the body and put to one side

Inserting sack



Locate the sack around the rear of the body, slide the edges of the sack around the sack retention posts in the moulding



Pull the sack taut and fold over the sack retention frame. Tuck the edges of the bag inside the bin body



Sack in frame and secure inside bin body

Repeat for second sack retention frame if the Meridian Envirobin has two waste collection receptacles

User Guidelines

Meridian Envirobin

Replacing the lid



Locate the rear peg of the lid under the lip at the back of the body



Place the lid back in position ensuring the front pegs locate in the body