


User guidelines

litter bins

Novelty



Cleaning Products should be flushed with clean water and then washed with a mild detergent solution using a bristle brush or sponge. Care should be taken not to apply undue pressure that may damage labels. Flush clean with water after washing.




Manufacturing Standard (as applicable)

All products are manufactured to BS EN ISO 9002.
Plastic materials: Mechanical properties tested to BS 2782 Hot dipped galvanized: BS 729
Powder coating: BS 3900 Zinc coating: BS 1706



Tools Key:




PPE Always wear appropriate PPE equipment and follow safety guidelines

Unlocking and removing hood



Insert key and turn clockwise until stop. Lock will pop out and release



Twist bin top and lift until it releases




Lift hood up and clear of bin body

Removing and replacing liner



Grip liner using two handles




Lift liner upwards clearing bin body and empty




Using handles to grip, replace liner


Replacing hood and locking



Replace hood onto bin body and twist until it drops to its lowest position



Rotate the hood in the desired direction until a step is reached.



Push lock in to engage