


User guidelines

Recycling bins

Envirocup bin



Cleaning Products should be flushed with clean water and then washed with a mild detergent solution using a bristle brush or sponge. Care should be taken not to apply undue pressure that may damage labels. Flush clean with water after washing.



Manufacturing Standard (as applicable)
All products are manufactured to BS EN ISO 9002.
Plastic materials: Mechanical properties tested to BS 2782 Hot dipped galvanized: BS 729
Powder coating: BS 3900 Zinc coating: BS 1706



Tools None



PPE Always wear appropriate PPE equipment and follow safety guidelines

Removing hood and water jug



1 Grip hood and lift upwards and clear bin body



2 Grip central excess liquid resevoir by top handle and lift from central core



3 Remove excess liquid resevoir and empty contents

Removing cup holder and liner



Grip cup holder on edge and lift up disengaging clips from bin edge



Lift cup holder upward clearing bin body. Cups will remain in the sack



Gather liner and remove

Replacing liner and cup holder



Stretch liner over the bin body and push down into the bin



Replace cup holder orientate so that metal clips align with the front and back of the bin



Drop cup holder down to its lowest level so that the front and rear clips hook over the bin edge

Replacing jug and hood



Replace excess liquid reservoir into central core



Replace hood so that label faces the front of the bin and lines up with any logos or personalisation



Push down ensuring the hood is seated at its lowest position