


# User guidelines

## Consort



**Cleaning** Products should be flushed with clean water and then washed with a mild detergent solution using a bristle brush or sponge. Care should be taken not to apply undue pressure that may damage labels. Flush clean with water after washing.



**Manufacturing Standard** (as applicable)

manufactured to BS EN ISO 9002.

Plastic materials: Mechanical properties tested to BS 2782 Hot dipped galvanized: BS 729

Powder coating: BS 3900 Zinc coating: BS 1706



**Tools Key:**



**PPE** Always wear appropriate PPE equipment and follow safety guidelines

### Unlocking and removing hood



1 Turn key anti-clockwise until it stops and remove key. The lock will disengage and the hood, spring anticlockwise slightly

2 Gripping bin apertures twist hood anticlockwise until resistance is met

3 Lift the hood upwards clearing the bin liner

Removing hood and liner



Place hood onto ground



Using the two handles grip liner



Lift liner up and over base and empty

Replacing Liner and hood



Relocate liner into base



Replace hood positioning over liner and lower onto base



Twist hood until it drops to lowest position

Engaging Lock



With bin hood resting on base, twist hood clockwise



Push in the plunge lock to engage and secure the lid.